

# Taş Dizme Stone Setting Makinesi Device

## Pokriq



Mumdan üretilen takılardaki taşların mum modele dizilmesi işlemi için mükemmel bir cihaz. Taşlar, sıcaklığı hassas bir ayarda tutan dijital kontrollü özel tasarlanmış ısıtıcı tablada ısıtılır ve cihaza bağlı vakumlu kalemle alınıp taşınmak suretiyle doğrudan doğruya mum veya reçine model üzerine yerleştirilir. Tabla sıcaklığının hassas kontrolü sayesinde taşların aşırı ısınması söz konusu olmadığından, taş mihlama işlemi mum veya reçine modelde tahribata yol açmadan gerçekleştirilebilir. Kullanımı son derece kolay bir elektrikli cihazdır. Ayrıca bir vakum pompası gerektirmez.



Model	TDC-11
Taş Tablası Ebadı Stone tray dimensions	2x7 cm (2 ad./pcs.)
Elektrik Özellikleri Power Supply	90 W, 230V AC 0,4 A, 50/60 Hz
Dış Ölçüler (e×b×y) Dimensions (w×l×h)	20×41×37 cm
Ağırlık Weight	4 kg

This device is a perfect solution for the wax setting system. Stones are warmed up on a specially designed heating plate and picked up with the built-in vacuum pen. This makes it possible to fix the stones directly into the wax or resin pattern by melting the surface of the wax. The temperature of the heating plate is controlled digitally in order to avoid destroying the wax or resin pattern due to excessive heat. It does not require any external vacuum pump.

### TEKNİK DÖKÜM Kaplama Malzemeleri Sanayi ve Ticaret A.Ş.

Main Office: 29 Ekim Cad. No:47/1 Ceritler Binası 34197 Yenibosna, Bahçelievler-Istanbul/TURKEY Tel: +90 212 652 19 94 Fax: +90 212 652 19 97

Kuyumcukent Branch: 29 Ekim Cad. Atölye Bloğu, Zemin Kat, 1. Sok. No:1 34197 Yenibosna, Bahçelievler-Istanbul/TURKEY Tel: +90 212 603 01 43 Fax: +90 212 603 01 40